

LaserMax

LMS-1200MAS Momentary Activation Switch for the LMS-1202 Shotgun Laser/Light

Installation & Operation

Step 1: Plug the remote switch into the jack to the right of the red on/off button.

Step 2: Clean a spot on the shooter's **left** side of the shotgun forearm using the enclosed alcohol wipe.

Step 3: Mount the Velcro switch pad to the cleaned area. Do not attach the pad to the shooter's right side of the forearm. Make sure the pad is mounted so that the coil cord doesn't interfere with the action of the pump.

Step 4: Push in the red on/off button.

Step 5: Squeeze the remote switch pad to activate the laser and light. Release the pressure on the pad to turn the unit off.

The remote switch is not operational unless the red button is pushed in. With the red button pushed in and the remote switch jack plugged into the laser/light, the laser and light will come on when the remote switch pad is squeezed. If the jack gets pulled out while the red button is pushed in, the laser and light will come on.

Cleaning

Simply wipe off any dirt and oil with a damp cloth followed by a dry one.

LaserMax, Inc.
3495 Winton Place, Building B
Rochester, NY 14623
1-800-LASER-03
Fax: (585) 272-5427
www.lasermax.com