



## PARTS IDENTIFICATION

### Right Housing



### Left Housing






**IMPORTANT:** Prior to installation, battery change, cleaning or maintenance, follow the firearm operator's manual to ensure that the firearm is unloaded.

## INSTALLATION



**!** This state-of-the-art laser sighting system is designed for use with a specific pistol platform. Do not attempt installation on any other firearm model/s.

1. Place rear portion of *right housing* on trigger guard of pistol as shown (figure 1).
2. While applying upward pressure to rear portion, press *right housing* firmly into place aligning channel in *right housing* with trigger guard (figure 2).
3. Insert rear portion of *left housing* into the *right housing* at a 45 degree angle (figure 3).
4. Mate *left housing* with *right housing*, ensuring that *activation switch* passes through opening in left housing. Press together to remove gap.
5. Install two (2) *mounting screws* into left housing with 5/64 *hex tool*, starting with longer screw closest to barrel (figure 4). Next, tighten each *mounting screw* until secure. Do not over-tighten; this may damage the CenterFire® housing.



## OPERATION

1. To turn the laser on, press in on the *activation switch* from either side (figure 5). Press again to turn the laser off.
2. To switch aiming point from pulse to steady, press and release the *activation switch* from either side to activate the laser. Then, press and hold the *activation switch* for 5 seconds. The laser mode will change. Repeat the process to return to the previous mode.
3. To save power and prevent inadvertent battery drain, the CenterFire® will shut off automatically after a ten minute period of inactivity. Cycle the *activation switch* to turn laser back on.



## ALIGNING THE LASER

1. Verify proper alignment by comparing laser aiming point to iron sights at a distance of 10 yards for initial alignment. The laser dot should be slightly above the iron sights.
2. To make adjustments, insert *alignment tool* into one of the two alignment ports (figures 6 & 7) and slowly rotate the tool while comparing laser position on target to fixed sights. **Important:** Do not rotate *alignment tool* more than one full turn in either direction from the factory position. This may cause damage to the laser and void the warranty. A one quarter turn will result in a movement of approximately 3 inches at 10 yards.
3. Windage adjustment: with the muzzle pointing forward and *alignment tool* inserted into the windage port, a clockwise turn will shift the laser aiming point to the left and a

counterclockwise turn will shift the laser beam to the right (figure 6).

4. Elevation adjustment: with the muzzle pointing forward and *alignment tool* inserted into the elevation port, a clockwise turn will shift the laser beam up and a counterclockwise turn will shift the laser beam down (figure 7).




5. Verify the laser alignment by shooting at a target and making additional adjustments as needed.

Note: a slight shift in alignment may be observed after firing the first time. Recheck alignment after first use and readjust as necessary.

## BATTERY REPLACEMENT

**TIP:** During periods of non-use, test the LaserMax laser periodically to ensure adequate battery levels.

1. Remove *mounting screws* to separate left housing from CenterFire® assembly.
2. Lift expended 1/3N Lithium battery out of *right housing*.
3. Install a fresh 1/3N Lithium battery with the positive (+) facing coiled spring. (figure 8).
4. Reinstall left housing as previously described in INSTALLATION section, Step 4.
5. Verify the laser alignment by shooting at a target and making additional adjustments as needed.



## CLEANING & MAINTENANCE

After repeated fire, the lens may become clouded with gunpowder residue. For best results, it is recommended that this area be cleaned, along with the firearm, after each use. To clean the lens, follow these steps.

1. Keep firearm pointed in a safe direction.
2. Confirm laser is off.
3. Dampen the end of a cotton swab with isopropyl alcohol.
4. Apply dampened swab to lens and polish in a small circular pattern. Be sure to clean around edges of lens.

Firearm should be cleaned and lubricated exactly as directed in the Sig Sauer Owner's Manual. Excess lubricant can interfere with the proper function of both the firearm and the CenterFire® laser. LaserMax components should never be submerged or flushed with cleaning solvents. Failure to adhere to these guidelines may cause damage and void the factory warranty.



See this sight installed at [www.youtube.com/LaserMaxInc](http://www.youtube.com/LaserMaxInc).

LASERMAX PRODUCTS LIMITED WARRANTY

LaserMax Products is pleased to offer a five (5) year limited warranty for this product. To take advantage of the coverage under this warranty, the product must be registered no later than 90 days after purchase.



This product may be registered by completing a Registration Form which may be found at [www.lasermx.com/support](http://www.lasermx.com/support) or by contacting the LaserMax Products Customer Service Department at 1-800-527-3703. The LaserMax Products Limited Warranty extends specific legal rights to the registrant. Other rights, which vary from state to state, may also apply. This product is warranted to be free from defects in material and workmanship at the time of purchase. This limited warranty does not cover expendable parts (ex: batteries), that have definite and predictable life expectancies. This warranty does not cover products that LaserMax Products determines have been exposed to abnormal use in any way. Examples of abnormal use include, but are not limited to, damage from mishandling, misuse or abuse, damage from exposure to abnormal conditions, damage from improper care and maintenance, or installation of the product in or on any firearm model the product is not specifically advertised to be used with. Warranty coverage begins on the date of purchase and ends five (5) years after date of purchase. This limited warranty extends only to the original registrant and is non-transferable. To file a warranty claim, a warranty repair request must be submitted, and a Return Merchandise Authorization (RMA) number issued by the LaserMax Products Warranty Department, within five (5) years from date of purchase. Following submission of a warranty claim, LaserMax Products reserves the right to inspect the product to determine its eligibility for warranty coverage. If deemed eligible, LaserMax Products will repair or replace the part(s)/product that LaserMax Products, at its sole discretion, determines to be defective during the warranty period. If deemed ineligible, LaserMax Products will return the part(s)/product with an explanation of why coverage is not available. LaserMax Products reserves the right to replace defective part(s)/product with an equivalent substitute product at its sole discretion. Any and all implied warranties, including the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, also begin on the date of purchase and end five (5) years after date of purchase. This limitation does not apply to residents of states that disallow limitations on the length of implied warranties. The preceding process is both the exclusive remedy and LaserMax Products exclusive liability for any warranty claim. LaserMax Products will not, under any circumstances, be liable for any incidental, indirect, consequential, punitive or exemplary damages (even if LaserMax Products has been notified of the possibility of such damages) resulting from or related to a product, including, without limitation, any loss of profit, opportunity, or damages in excess of the purchase price of the warranted product. This limitation does not apply to residents of states that disallow limitations on incidental or consequential damages. LaserMax Products is a unit of Crosman Corporation.

LaserMax Products  
A Velocity Outdoor Company  
7629 Routes 5 & 20, Bloomfield, NY 14469  
800-527-3703 • [www.lasermx.com](http://www.lasermx.com)


For patent information, please visit:  
[www.lasermx.com/patents](http://www.lasermx.com/patents)  
CF-P238-515



View complete installation and battery replacement video tutorials at  
[www.youtube.com/LaserMaxInc](http://www.youtube.com/LaserMaxInc).

REPLACEMENT PARTS

LMS-AT50	.05" adjustment tool
06297-0-1	5/64 hex tool
LMS-13N	replacement battery
LMS-2x13N	2-pack replacement batteries
06233-0-1	long mounting screw
06324-0-1	short mounting screw



CF-P238  
Red Laser  
CLASS 3R VISIBLE LASER  
Output Power: <5mW  
Wavelength: 600-700nm

REMINDER  
Aiming a laser beam at moving vehicles including boats, aircraft, trains, and construction equipment may be illegal. Check current applicable laws and follow them accordingly.

DANGER  
Laser radiation is emitted from the front aperture of the laser when the switch is activated.

WARNING  
Avoid direct eye exposure to beam. Do not point laser at anything you do not wish to destroy.  
NOTICE:  
The FDA requires the label supplied with your laser be affixed to the outside of the gun near the laser aperture.

IF YOU EXPERIENCE AN  
ISSUE WITH YOUR LASER  
PLEASE DO NOT RETURN IT  
TO THE STORE.

Contact LaserMax Customer Service: 800-527-3703



CENTERFIRE®

LASER SIGHT



Operator's Manual